

Change Ring Tones



Office 5370 and 5380 Desk-phones

Setting the ringing properties

You want to change the way in which your phone rings.

You can adjust the *Ringling volume*, the *Internal melody*, the *External melody*, and the *Speed*.

Menu



Press the *Menu* Foxkey.

Settings



Scroll to *Settings* and press the *Select* Foxkey.

Audio



Scroll to *Audio* and press the *Select* Foxkey.

<Audio setting>



Scroll to the required audio settings and press the *Modify* Foxkey.

<Setting value>



Select the required setting and confirm with the *Ok* Foxkey.

→The setting is stored.

Note:

To list to all the settings, use the *Test* Foxkey.

Change Ring Tones



Office 5361 Desk-phones Setting the ringing properties

You want to change the way in which your phone rings.

You can adjust the *Ringing volume*, the *Internal melody*, the *External melody* and the *Speed*.

Menu



Press Foxmenu, then Foxkey *Menu*.

Settings



Scroll to *Settings* and press the *Select* Foxkey.

Audio



Scroll to *Audio* and press the *Select* Foxkey.

<Audio setting>



Scroll to the required audio settings and press the *Modify* Foxkey.

<Audio setting>



Select the required setting and confirm with the *Ok* Foxkey.
→The setting is stored.

Note:

To list to all the settings, use the *Test* Foxkey.