

Call Forward to Voice Mail



Forwarding to voice mail

You cannot momentarily be reached on your phone. If you forward to your voice mail, a user can leave you a voice message.

Notes:

- A forwarding applies to all connected phones.
- Only one forwarding variant at a time is possible.

Office 5730 / 5370 (multi line display)

Menu



Press the *Menu* Foxkey.

Forwarding



Scroll to *Forwarding* and press the *Select* Foxkey.

Call Forwarding Unconditional



Scroll to *Call Forwarding* and confirm with the *Ok* Foxkey.

Voice mail



Scroll to *Voice Mail* and confirm with the *Ok* Foxkey.
→ Forwarding is activated.

Office 5360 / 5361 (single line display)

Menu



Press Foxmenu, then Foxkey *Menu*.

Notes:

- You can specify whether your voice mail should answer directly (*Call Forwarding*) or with a delay (*Call Forwarding on No Reply*), or only if you are already on the phone (*Call Forwarding Busy*).
- You can deactivate forwarding using *Menu > Activated features > Reset*.
- A new voice mail message is signalled with a text message on the display and a lit indicator LED in the idle state.

Alternatively: to quickly forward all calls to voice mail

Dial 899 and Press the  **Absence Key*** it will now show active 

Press the **Absence Key** again to cancel. Note: the Absence Key remembers the last destination set, therefore should you wish to forward to Voice Mail again simply press the Absence Key.

* The function and working of this button may vary depending on system configuration. Please refer to your system administrator.