

Check Lines – ISDN 2e



ISDN 2e line box

Located near the AASTRA system

Solid green light:

Indicates good connection with BT Exchange and Telephone system

Slow flashing green light:

Indicates connection lost with BT Exchange

Fast flashing green light:

Indicates bad connection / faulty connection to BT Exchange

NO green light:

Indicates no connection to BT Exchange